


Air - Workings on the aluminium-framed doors for holders




Workings on the aluminium frame DEL6LP300_.

Dimensions of the frame 26x26 mm.



Formulas to determine the distance for the insertion of the holders for arm.




$$A = B + 4$$

$$B = A - 4$$




Workings on the aluminium frame DEL9LP300_.

Dimensions of the frame 26x19 mm.



Formulas to determine the distance for the insertion of the holders for arm.





$$A = B + 4$$

$$B = A - 4$$

Air - Aluminium frame assembly

The profiles which make up the door must be cut and the ends mitred at 45°, and milled for the insertion of the corner connectors.

Insert the corner connectors into the profile and fix them with the screws provided.



Insert the hinges into the recesses.

Fix with the screws provided.

